

# DP41i

This section covers Technical Questions and Answers on the product below.

## DP41i Rate Download Instructions

If your machine is in standby mode, please press the standby key.

1. Press the connection key.
2. The screen will display the following message: 504-Inspection CNX.DAT.CEN
3. Press the 'OK' button.
4. The screen will now display the following messages:

Connection in progress.  
Distribution OK.  
Msgs OK.  
Commet Server OK.  
Step 1.  
Step 2.  
UPD xxkb/1min.  
Internal Checking.

During this process the screen may go blank several times  
You should now be returned to the normal screen and the download should be complete