

Rate Pack Fitting Instructions

SE-37/57/107

THIS RATE PACK MUST NOT BE LOADED UNTIL THE DATE OF RATE CHANGE

1

Using switch at rear of machine turn scales off

2

Gently remove the weigh platform by easing it up at the front and back



3

Remove the rate pack cover and extract the old rate chip



4

Install new rate pack with black component facing rear of the scale



5

Re-fit weigh platform, ensure the platform is front facing
(front is written underneath platform)

FOR ENVIRONMENTAL PURPOSES PLEASE DO NOT FORGET TO RETURN PACK, USING ENCLOSED ADDRESS LABEL.

If experiencing any problems after loading turn the Machine OFF then ON.

